

EN • Legs Beauty Consult (Temp FX, Cellu Belt FX, Software package)

Device for aesthetic use. Does not perform diagnosis and treatments.

Cod. 600316

Manufacturer

Callegari S.r.l.

Description and Intended Use

Legs Beauty Consult (Temp FX, Cellu Belt FX, Software package) is an optional package available with Soft FX and composed of three components: the TEMP FX, The Cellu Belt and the software package.

TEMP FX is a probe which measures skin surface temperature via detection of infrared emissions and without contact with the skin. It is used in combination with Soft FX.

Plastic belt to be used as accessories when Soft FX Cellulite Specialist Program is performed.

Soft FX is a device used to establish and assess the main skin parameters, for aesthetic, non-diagnostic purposes. The device is intended to be used in chemist's shops, OTC retailers, beauty salons, spas, wellness centres, aesthetic medicine centres and other locations where skin analyses are performed for purely aesthetic reasons. The instrument does not require specialised personnel.

Soft FX skin analysis system is a modular device which consists of the following components: machine body, Melanin – Hydration probe (MEL-HYD FX), Elasticity probe (ELA FX), microcamera (CAM FX - skin). Consumables for the sebum analysis (TAPE FX) are required.

TECHNICAL FEATURES OF THE TEMP FX PROBE

TECHNICAL FEATURES TEMP FX: temperature probe	
APPEARANCE	Pen-type probe, made of PC/ABS with sensor and optical pointing system on the tip and magnetic coupling to place it in the universal probe support
WEIGHT	Weight: 98 g (batteries included)
DIMENSIONS	43.5 (w) x 144 (d) X 21.5 (h) mm
OPERATING CONDITIONS	Temperature +16 °C – +40 °C (Relative humidity: 15-93% uncondensed)
STORAGE CONDITIONS	Temperature -25 °C – +70 °C (Relative humidity: 5 – 85% uncondensed)
CONNECTIVITY	Bluetooth Low Energy (BLE)
POWER SUPPLY	4 1.5V alkaline AAA (LR03) batteries
AUTONOMY OF 4 BATTERIES	10,000 readings
RF MODULE (BLE)	Operating frequency bands: 2402-2480MHz Transmit powers: -12dB - 9dBm
MEASURING SENSOR	<ul style="list-style-type: none"> MEASUREMENT PRINCIPLE: detection of infrared emissions for measuring skin surface temperature without touching it. The probe has an optical pointing system that projects 4 arcs onto the surface to show its correct reading distance. FIELD: 1.0 - 80 °C RESOLUTION: 0.1

TECHNICAL INFORMATION CELLU BELT

PRODUCT INFORMATION: CELLU BELT	
INTENDED USE	Plastic belt to be used as accessories when Soft FX Cellulite Specialist Program is performed.
MATERIAL	100% polyester fabric coated with PVC.
TYPE	Spare part.